

## FRONT FOGLAMP WIRING LOOM

### T5 2003-2010

JK Part Number J39911

#### FITTING GUIDE

1. The red wire with the inline 20 amp fuse connects, directly to the positive (+) battery terminal.
2. The black wire connects directly to the negative (-) battery terminal.
3. The green wire comes fitted with the correct connector to fit straight into the 17 pin connector plug which connects to the back of the headlight switch using the number 8pin.
4. The vehicle headlight connector block that plugs into the back of the headlight switch, is numbered 1 to 17 very clearly so you can't go wrong.

9	8	7	6	5	4	3	2	1
NSL	NL	56	B	560	56	TFL	Xr	Xz
58d	58	30	58R	58L	SRA	31		
17	16	15	14	13	12	11	10	

- |   |   |
|---|---|
| 9. REAR fog lights                        | 17. PLUS connection in instrument panel |
| 8. FRONT fog lights                       | 16. Power for front FOG lights          |
| 7. Power to passenger compartment from Xz | 15. Power                               |
| 6. OPEN power back to instrument panel    | 14. RIGHT parking light                 |
| 5. Nothing                                | 13. LEFT tail and side parking lights   |
| 4. Headlights                             | 12. Nothing                             |
| 3. OPEN power back to instrument panel    | 11. OPEN power                          |
| 2. OPEN to instrument panel w/15A fuse    | 10. GROUND                              |
| 1. Ignition switched power                |   |

*N.B. Whilst every attempt is made to ensure that these instructions are as accurate and clear as possible, we cannot be held responsible for misinterpretation of these instructions or for any subsequent accident or damage caused through mis-fitted parts.*