





J29214 and J39427

SIDE BAR FOR VW T5 10+(LWB/SWB)



RHS



LHS

COMPONENTS LIST

1. 2. 3. 4. 5. 7. 8. 9. 10. 11.

6.


ITEM No.	COMPONENTS	QTY.
1	Side Bars	2
2	Front Brackets	2
3	Rear Brackets	2
4	Threaded Plates	8
5	M8 Spring Washers	8
6	M8 Washers	8
7	M10 Spring Washers	4
8	M8 Nuts	8
9 **	M10 Screw	4
10	M10 Washers	4
11	Lock	8

** Please note the item 9 - M10 Bolts have been replaced with a Nut and Stud (With allen key holding end)


IMPORTANT:

- This product must be installed exactly as specified in these instructions. Failure to do so may result in improper fit and/or inadequate tension.



Components	Qty	Part
1. SIDE BRASS	2	
2. FRONT BRACKET (Right Side)	1	
3. FRONT BRACKET (Left Side)	1	
4. REAR BRACKET (Right Side)	1	
5. REAR BRACKET (Left Side)	1	
6. TRENCH PLATE	8	
7. LOCK	8	
8. 1/8 x 1.25 Hex Nut - 30 Ns	8	13
18 Lockwasher	8	
19 Washer	8	
9. 110rl. 5x40	4	17
110 Lockwasher	4	
110 Platewasher	4	





INSTRUCTIONS



1. Identify the front and rear brackets, as shown. Thoroughly clean the installation areas.





2. Remove the front splash shield "A" by unscrewing the retaining bolts. 3. Remove the rear splash shields "C" by unscrewing the retaining bolts.





4. Remove the rubber caps "D" from the sill rail in the chassis from the front and rear of the vehicle which align with the holes in the mounting brackets.

5. Once the rubber caps are removed. Insert the threaded plates "E" inside holes on the chassis so its threaded ends are exposed. Do this for the front and rear. Once installed, slide the lock into the threaded plate in the threaded section as shown. This is to stop the threaded plate from being pushed inside the chassis.



6. Place front bracket on the thread plates so its threaded ends extends through the bracket and secure with M8 washers, M8 spring washers through the bracket and secure with M8 spring washers, M8 washers and M8 nuts . and M8 nuts.


7. Place rear bracket on the thread plates so its threaded ends extends



8. Hold the Side Bar into position and attach using M10 screws,

M10 washers, and spring washers. Tighten all bolts fixing bracket to vehicle, then finish by tightening the bolts holding the side bar to the brackets using the following torque settings as a guide.

THREAD SIZE	TORQUE SETTING	SPANNER / SOCKET SIZE
M8	20Nm	10mm
M10	41Nm	17mm



10. Before re-installing splash shields, it is necessary to remove some material from the splash shields to allow clearance for the M8 nuts on the mounting brackets. On the front splash shield, from the front edge measure along 180mm (SWB) and make a cut 25mm deep. Make another cut a further 30mm from this cut, also 25mm deep and remove the section of material. Then take another measurement from the front edge of 480mm (S WB) and repeat the procedure for removing another section of material, 25mm x 30mm. On the rear splash shield, from the back edge measure along 120mm (SWB) and make a cut 25mm deep. Make another cut a further 30mm from this cut, also 25mm deep and remove the section of material. Then take another measurement from the back edge of 450mm (SWB) and repeat the procedure for removing another section of material, 25mm x 30mm. Apply these principles for long wheel base with the correct measurements.



Clean Side Bars with a mild

Do not use abrasive cleaners, detergent and water solution.